

Brodware

Pull Out Kitchen Mixer Instruction Card

- 1) Ensure you have a minimum of 550mm vertical clearance under the hob, to accommodate the pull out hose system.
- 2) Make sure that all lines have been properly flushed. Ensure that the static water pressure does not exceed 500kpa , as per ASS3500. If pressure exceeds this, install Pressure Limiting Valves. Failure to do so will void the warranty.
- 3) Ensure that the hole size in the bench / hob is 35mm in diameter. Keep in mind that the maximum pull out reach is 345mm.
- 4) Remove the Mounting Nut and Washer from the mixer assembly. Remove the Counter Weight off the pull out hose.
- 5) Slide mixer through the top side of the bench / hob. Refit and tighten Mounting Nut and Washer to the under side of the bench Hob.
- 6) Check and test the pull out hose, and ensure that it can be pulled out freely and easily , and ensure there are no obstructions to the hoses. Refit the counter weight 385mm from underside of mounting nipple to centre of counter weight.
- 7) Connect the Hot and Cold hoses to the stop cocks (not supplied) under the bench / hob. Tighten the hose connections, then turn them both on.
- 8) Check the mixer for general functionality and leaks. Check that spray head works correctly.

NOTE FOR INSTALLER:

*Ensure this installation meets Australian Standards ASS3500.

*Refer to the Brodware Mixer Instruction Booklet for all other technical information.

